



Fraserway RV

SCOUT OLYMPIC



Instruction Manual

ENGLISH



Fraserway RV



FOUR SEASONS
RV RENTALS BY FRASERWAY

ONROAD SUPPORT: 1-866-535-6601 OR 604-636-3057

Welcome to the Open Road: Your Adventure Starts Now!

On behalf of the entire team, we extend our heartfelt thanks for choosing **Fraserway RV Rentals** or **Four Seasons RV Rentals** as your partner in exploration.

We are truly delighted that you have decided to embark on your journey with one of our quality motorhomes. We believe the freedom and flexibility of an RV vacation provides the perfect setting for creating **unforgettable memories**, and we sincerely wish you a **safe, successful, and truly exceptional trip**—the vacation of a lifetime!

This comprehensive Customer Manual is designed to be the single most important resource you carry with you. We understand that operating a motorhome is new to many travelers, and our goal is to ensure you feel **confident and prepared** from the moment you leave our lot until the moment you return.

Within these pages, you will find:

- **Crucial Travel Rules and Regulations**
- **A Detailed Description of Your Motorhome and its Appliances**
- **Clear, Step-by-Step Instructions**
- **Quick Reference Troubleshooting**

We encourage you to take a few minutes to familiarize yourself with this manual now. Having this knowledge at hand will help you relax and focus entirely on the beautiful sights and experiences awaiting you.

Safe travels, and we look forward to hearing about your incredible journey!

Your Fraserway and Four Seasons Rentals team



ONROAD SUPPORT	3
CANADIAN TRAFFIC RULES AND ROAD SIGNS.....	5
ROAD SIGNS.....	9
CABIN	10
IGNITION.....	10
AUTOMATIC TRANSMISSION	10
TOW/HAUL.....	10
CRUISE CONTROL.....	11
PARKING BRAKE.....	11
LIGHTS.....	11
DRIVE MODES	11
DRIVER INFORMATION DISPLAY OVERVIEW	12
VEHICLE CARE AND MAINTENANCE.....	13
TIRES.....	13
VEHICLE SPECIFICATIONS	14
EXTERNAL VIEW	15
ELECTRICAL SYSTEM.....	16
WATER SYSTEM	17
TOILET.....	17
OPERATING THE DIESEL HEATER	17
FRIDGE.....	18
AWNING	18
BEDS	18
SAFETY EQUIPMENT.....	19
FIRE EXTINGUISHER.....	19
SMOKE DETECTOR/CARBON MONOXIDE ALARM	19
PROPANE DETECTOR/ALARM	19
RETURNING THE VEHICLE.....	20



ROADSIDE ASSISTANCE

If you experience any issues with your RV during your travels, please contact our **Fraserway & Four Seasons OnRoad Support Service**. Our team is here to help keep your journey smooth and enjoyable.

Emergency Service Numbers

Toll-free: **1-866-535-6601**

Direct: **1-604-636-3057**

Emergency Service Hours (Pacific Time – BC & Yukon)

- **Monday to Friday:** 5:00 am – 8:00 pm
- **Saturday, Sunday & Holidays:** 6:00 am – 6:00 pm

Email: onroadsupport@fraserway.com

Please note that these hours follow the **Pacific Time Zone** (British Columbia & Yukon): **UTC-8**, or **UTC-7** during daylight saving time.

If you call **outside of these hours**, your call will be answered by our after-hours service. They'll take your information and forward it to us, and we'll contact you as soon as possible during regular business hours. The **Fraserway & Four Seasons OnRoad Support Service** is available from **April 1 to October 31, 2026**.

Before You Call – Please have the following information ready:

- **Your Rental Agreement Number** (*found in the upper left corner of your rental agreement*)
or
Your Unit Number (*found on your key tag*)
- **Your exact current location** (*Province, city, street or intersection, campsite name, pitch number*)
- **Your upcoming travel plans** (*Planned campgrounds and cities for the next 2–3 days*)
- **A clear description of the issue** (*Please describe the problem in as much detail as possible*)

Important: Without the above information, we may not be able to identify your booking or reach you if you need to leave a message.

Thank you for your cooperation — it helps us get you back on the road faster!

IN CASE OF AN ACCIDENT

Your safety is always the top priority. If you're involved in an accident, please follow these steps:

1. **Check for injuries.**
Make sure everyone is safe and determine if anyone needs immediate care.
2. **Call for help if needed.**
If anyone is injured or there's significant damage, call **9-1-1** right away for police or medical assistance.
3. **Let us know what happened.**
Once everyone is safe, please contact the **Fraserway & Four Seasons OnRoad Support Service** to report the accident.
4. **Exchange information.**
Share and record important details with the other people involved, such as:
 - Names, addresses, and phone numbers
 - Insurance companies and policy numbers
 - Driver's license numbers and vehicle information (including license plate)
 - If the driver and insured person are different, note both names and their relationship
5. **Gather details at the scene.**
Use the **Accident Report Form** located behind the driver's side visor to write down:
 - Vehicle make, model, color, and year
 - Street names, intersections, or nearby landmarks
 - Police officer names or ID numbers, and the incident number (if available)
6. **Take photos.**
Snap clear pictures of the accident scene and all vehicles involved — especially any visible damage. If there are witnesses, please note their names and contact details, as this can help later if there are any questions or disputes.

Tip: Staying calm and gathering accurate details will help us assist you quickly and efficiently — and get you safely back on the road.

	Phone No.	Monday - Friday	Saturday	Sunday/Holiday
Fraserway / Four Seasons OnRoad Support Service	1-866-535-6601* and 1-604-636-3057 (Mon-Fri: 5am-8pm, Sat, Sun and holidays: 6am – 6pm)			
Police/Ambulance	9-1-1	24/7	24/7	24/7
Ford Roadside Assistance	1-800-665-2006*	24/7	24/7	24/7
Dodge Roadside Assistance	1-800-363-4869*	24/7	24/7	24/7
Kal Tire 24-Hour Roadside Assistance (Tires only)	1-888-525-8473*	24/7	24/7	24/7

Note: Phone numbers marked with * are toll free from a landline. Charges may apply when calling from a mobile phone.

CANADIAN TRAFFIC RULES AND ROAD SIGNS

DRIVER'S LICENSE REQUIREMENTS

A **valid national driver's license** is mandatory for all RV rentals. While most foreign licenses are generally accepted across Canada, we strongly recommend that drivers whose licenses are *not* issued in English or French also carry an **International Driving Permit (IDP)**. An International Driving Permit is only valid in combination with your valid national drivers' license.

ALCOHOL AND DRUGS

Your Safety is Our Priority: Please be aware that blood alcohol and drug limits for operating a vehicle are strictly mandated by provincial and territorial laws. We strongly urge you to **never drive under the influence** to ensure your well-being and adhere to all legal requirements.

SEAT BELT SAFETY

Mandatory Seat Belt Use: For your safety and compliance with Canadian and U.S. laws, **the driver and all passengers must have their seat belts properly fastened** at all times while the vehicle is in motion.

ROAD SPEED REGULATIONS

Be advised that the default speed limit is **50 km/hr in most urban areas** and either **80 or 100 km/hr on highways**, unless a different speed is clearly indicated by posted signs.

PEDESTRIANS

Road Courtesy: Please note that Canadian drivers generally operate with a **polite and considerate manner**. Always remember that **pedestrians have the legal right of way** and must be granted safe passage.

HIGH-OCCUPANCY VEHICLE (HOV) LANES

HOV lanes are designed to promote carpooling and public transit by restricting use to vehicles carrying a minimum number of occupants. The HOV symbol is a **diamond shape**, which is marked on the lane surface and posted on regulatory signs.



Example of signs:

Left: HOV Lane Starts: *HOV lane for buses and vehicles with at least 2 people starts here.*

Right: Time-Restricted HOV Lane: *From 5 AM to 11 PM, this lane is an HOV lane for buses and vehicles with at least 3 people only.*



Fraserway RVs allowed on HOV lanes: <ul style="list-style-type: none">• Van Conversion• Truck Camper• C-Small	Fraserway RVs NOT allowed on HOV lanes due to weight restrictions: <ul style="list-style-type: none">• C-Medium, C-Large, C-XLarge, ROF
--	--

INTERSECTION GUIDELINES AND TRAFFIC SIGNALS

Navigating intersections safely and courteously is crucial for a smooth journey. Please follow these guidelines regarding traffic control devices and right-of-way rules.

FOUR-WAY STOPS AND UNCONTROLLED INTERSECTIONS



When approaching a four-way stop, or any intersection where traffic lights are not functioning (treated as an all-way stop), follow these mandatory rules:

1. **Mandatory Stop:** You **must always come to a complete stop** at the designated stop line.
2. **Right-of-Way (Sequence):** The driver who arrived and came to a complete stop **first** has the right-of-way to proceed.
3. **Right-of-Way (Simultaneous Arrival):** If two vehicles arrive at the stop line at the exact same time, **yield the right-of-way to the vehicle on your right-hand side.**
4. **Courtesy and Flow:** In line with Canadian driving courtesy, drivers are typically disciplined and courteous. **Only one vehicle is permitted to cross the intersection at a time** to maintain orderly traffic flow.

TRAFFIC LIGHT MANEUVERS



- **Protected Left Turns:** A designated **left turn arrow** provides a protected turn, allowing you to safely proceed while opposing traffic is stopped by a red light.
- **Right Turn on Red (RToR):** In the U.S. and Canada, you may generally turn right on a red light **after coming to a complete stop** and confirming the intersection is entirely clear of vehicles, cyclists, and pedestrians.

! **Note on RToR:** The sole major exception to the Right Turn on Red rule is the **Island of Montreal in Québec.** Always obey clearly posted signs that prohibit RToR at specific locations.



Example on the left: Turning right is prohibited on red.

Example on the right: Turning right is prohibited from Monday to Friday, 7AM - 9AM and 4PM - 6PM (no matter whether there are traffic lights or not).



SCHOOL BUS SAFETY PROTOCOL



The safety of children is paramount. You **must** observe the following strict legal protocol when encountering a school bus.

Recognizing the Stop Signal

Canadian school buses are easily identified by their yellow color. When a school bus is **stopped** and signals using flashing red lights and/or a swing out stop sign:

- **All traffic must come to a complete halt.** This is a legal requirement to ensure children can safely get on and off the bus.
- **It is strictly against the law to pass a stopped school bus** that is signaling its stop. Failure to obey this rule is a serious offence.

Exceptions

- **Median Separated Roads:** Only if the road is physically separated by a **median** (a raised or unpaved barrier), may traffic proceeding in the opposite direction (oncoming traffic) slowly proceed without stopping.

Resuming Traffic

- Traffic may only move again in both directions once the **flashing lights have been turned off** and the **stop sign has been retracted.**

RESPONDING TO EMERGENCY VEHICLES

If an ambulance, fire truck, or police car approaches with **flashing lights and/or sirens** (whether from ahead or the rear):

- Immediately **pull over safely to the right side of the road** or traffic lane.
- **Remain stationary** until all emergency vehicles have completely passed your location

IF STOPPED BY LAW ENFORCEMENT

Should you be pulled over by a police vehicle, follow these steps to ensure a safe and professional interaction:

- Safely **pull over to the right side of the road** and turn off the ignition.
- **Stay inside your vehicle** and roll down the driver's window. Wait calmly for the officer to approach.
- Always keep your hands visible on the steering wheel.
- **Follow all instructions and orders** given by the officer.

ACCIDENTS AND DAMAGE PROCEDURES

In the event of an accident, your safety and adherence to proper protocol are paramount.

PREVENTATIVE PARKING SAFETY

Please be aware that **most vehicle damage occurs while maneuvering and parking the RV.**

- **Tip:** To easily prevent parking-related damage, we strongly recommend having a passenger **exit the vehicle and assist the driver** by giving clear, real-time directions.

AT THE ACCIDENT SCENE

Follow these steps immediately after an incident:

1. **Do Not Settle: Never settle or admit any wrongdoing or fault** at the accident scene.
2. **Call Police:** Call the Police immediately if required (note that the police may not attend minor accidents without personal injury).
3. **Gather Information:** If possible and safe, **take photographs, make detailed notes, and exchange information** with the other party involved.
4. **Stay Visible:** Keep your hands visible and follow all instructions if law enforcement attends.

REPORTING THE INCIDENT

- **Mandatory Contact:** You must **always call our OnRoad-Service** immediately following an accident.
- **Complete Report:** **Fill in the comprehensive Accident Report form** found in the envelope behind the driver's side visor

NAVIGATION AND VEHICLE HEIGHT RESTRICTIONS

It is **crucial** that you are always aware of your RV's dimensions, as standard GPS systems do not account for vehicle height restrictions.

- **Vehicle Specifications:** Your RV's specific **External Dimensions and Gross Vehicle Weight (GVW)** are clearly listed on the windshield sticker and within this manual.
- **GPS Limitation:** Standard GPS navigation systems **do not provide height restriction data**
- **Mandatory Checks: Always check for clearly posted restriction signs** before attempting to pass through:
 - Tunnels and Overpasses
 - Gas station canopies and roof constructions
 - Ferry entry points and ticket booths

! Important Warning: Structures such as drive-thrus at fast food outlets, entryways to hotels/motels and parking garages are generally too low for safe RV passage and should be avoided.

Clearance Requirement: The minimum vertical clearance needed for safe passage with any of our vehicles is 3.7 meters or 12 ft.

PARKING REGULATIONS AND SAFETY ZONES

Please be advised that while detailed parking regulations may vary by province and territory, the following general rules apply and must be strictly observed:

GENERAL PARKING RULE

- **Direction of Traffic:** As a general rule, parking is only permitted when your vehicle is facing the **driving direction of the traffic lane** on the side of the street where you park.

Important Parking Notice: Be aware that a yellow curb side typically signifies a no-parking area. Furthermore, when parking in a paid zone, you must ensure payment for the total number of parking spots your RV occupies.

PROHIBITED PARKING ZONES

For safety and legal compliance, parking is **strictly prohibited within 6 meters (approx. 20 feet) on either side** of the following fixtures and locations:

- Pedestrian crossings, Stop signs, Traffic control signals.
- Fire hydrants, Curves or corners.
- Entrance/Exit of hotels, theatres, schools, and fire departments.

TOLL BRIDGES AND CROSSINGS

To ensure a smooth return and prevent unnecessary administrative fees, please follow the guidelines regarding toll crossings:

- **Toll Notification (Post-Use):** If you are aware that you have crossed a toll bridge during your journey where payment was not made on the spot, you **must inform us upon return of the RV**.
 - **Note:** Fraserway RV is billed directly by the toll operator. Timely notification avoids additional administrative charges being applied to your final bill.
- **Direct Payment Crossings:** Some crossings require **direct payment on the spot**.
 - **Safety Priority:** When approaching a toll booth, always use the **truck lane** to prevent any potential issues with height restrictions.



ROAD SIGNS



One way street



Pedestrians are not allowed to cross the street here.



Crossing the road is only permitted at crosswalks.



Do not enter.



Vehicles parked in this zone without a permit will be towed.



Road is closed. The arrow points in the direction of the detour.



From this point, do not change lanes until further notice.



Authorized vehicles only (buses, emergency vehicles, etc.).



No parking on either side of the sign. If the arrow points in one direction only, do not park on the side it points to.



No stopping on either side of the sign.



This road or lane is for bicycle use only.



This road or lane is for buses only.



Private property. No parking.



Turn headlights on and remove sunglasses (common at tunnel entrances).




No parking from 8:30AM to 5:30PM. Parking is allowed during the remaining hours.



No parking except on Sundays and on holidays.



No parking. Loading zone.



Parking on both sides of sign daily 8:30AM - 5:30PM for 2 hours. Parking disks are not used in Canada.



Drivers travelling in opposite directions share the centre lane for left turns.



On multi-lane highways: Sign in combination with exit signs means that a lane ends and becomes the exit lane.



Control signal: Placed over lanes to indicate which ones are open for driving. Here: RED = do not drive in Right lane.



YELLOW: Move into one with a green arrow. If flashing yellow over all lanes: Slow down and proceed with caution.



Green arrow: Drive in this lane.

CABIN

POWERTRAIN AND ENGINE

Your Scout is loaded on the bed of a Ford F-150 V6 EcoBoost. It's engine displacement is 3.5 litres and an output of up to 325 hp. It features an automatic transmission, power steering, and power brakes for easy driving.

IGNITION

To start the engine

- Make sure your car key or fob is **inside the unit** (in your pocket, bag, or the designated spot).
- Place your foot firmly on the **brake pedal**.
- push the start/ignition button ①



To switch off the engine

- Press the button ① again without the foot on the brake pedal.

AUTOMATIC TRANSMISSION


The gear selector is located on the right-hand side, between the driver and the passenger seat, with the current position displayed on the instrument cluster. The brake pedal must be pressed to shift from Park into Reverse or Drive.

P	①	PARK	used to start or stop the engine and remove the key
R	②	REVERSE	To reverse the vehicle. It engages the rear-view camera automatically
N	③	NEUTRAL	select this position for towing only!
D	④	DRIVE	recommended for all normal driving
M	⑤	MANUAL	For manual shifting. Please do not use!




TOW/HAUL

Tow/Haul optimizes shifting and prevents transmission overheating, especially in mountainous terrain. It provides extra power uphill and engine braking downhill to reduce brake wear. Select this function by turning the drive mode switch ① counter clockwise ② until you see TOW/HAUL in the display ③.



CRUISE CONTROL

Cruise control works at speeds of 50 km/h or higher. It should not be used in mountainous areas, as frequent shifting may increase fuel consumption and potentially damage the transmission.




- ① Turn cruise control **ON** or **OFF** using the **ON/OFF** button.
- ② Accelerate to your desired speed and press **SET +** to maintain it (you can also use the pedal and then press **SET +**).
- ③ Press **SET -** to reduce speed.
- ④ Press **CANCEL** to pause the cruise control.
- ⑤ Use this button to select the automatic following distance for Adaptive Cruise Control (ACC). For optimal safety and reaction time, we recommend the **maximum setting, GAP DISTANCE 4 (Far)**. **Crucial Note:** The driver remains fully responsible for maintaining a safe distance and monitoring traffic, regardless of the ACC setting.
- ⑥ The dedicated button allows you to engage or disengage the **Lane Centering** system. Even when this feature is active, it is mandatory to maintain continuous, hands-on contact with the steering wheel.

PARKING BRAKE

To engage the parking brake, simply pull the lever ①, which is located on the left side of the steering wheel. To release the parking brake, simultaneously place your foot on the brake pedal and push the lever



LIGHTS



- ① Cargo Lamp
 - ② Front Fog Lamps
 - ③ Lamps OFF
 - ④ Parking Lamps
 - ⑤ Headlamps
 - ⑥ Automatic Lamps
 - ⑦ Instrument Panel Lights
- A Brighter
B Darker

DRIVE MODES



- 2H** Ideal for regular conditions and dry pavement.
- 4A** Automatically engages four-wheel drive power to maximize traction on varying on-road surfaces as needed.
- 4L** Provides maximum locked four-wheel drive power, primarily for navigating extremely low-traction situations.
- 4H** Engages locked four-wheel drive for off-road or challenging conditions (e.g., deep snow, mud). **Crucial Note:** Do not use on dry pavement and do not exceed 50 km/h.

We strongly recommend utilizing the 2H drive mode for all standard operation.

Please be advised that improper use of the 4x4 system may not be evident until a post-rental vehicle inspection. Therefore, we reserve the right to notify and charge renters after the vehicle is returned if misuse is detected.

DRIVER INFORMATION DISPLAY OVERVIEW

Our trucks are equipped with an advanced information display designed for driver interface.

This screen allows you to **monitor vehicle systems, receive alerts, and configure specific vehicle features.** When the engine is started, the display will show the **Instrument Cluster**, similar to the accompanying image.



- | | | |
|--|---|---------------------------------------|
| ① Tachometer (indicates engine speed) | ⑥ Speedometer (indicates vehicle speed) | ⑩ Info Center (see description below) |
| ② Engine coolant temperature | ⑦ Current mode (P, R, N, D or M) | ⑪ Compass |
| ③ Oil pressure | ⑧ Temperature (here in Fahrenheit) | ⑫ Odometer |
| ④ Configurable, for example oil pressure | ⑨ Current played music | ⑬ Vehicle is ready for driving |
| ⑤ Fuel gauge | | |

NAVIGATING YOUR TRUCK'S INFORMATION CENTER DISPLAY ⑩

This section of the steering wheel provides full access to your truck's system information. It allows you to quickly monitor and configure your vehicle.

Here is how to navigate the menus:

1. **Access the Directory:** Press the **MENU button ④** to open the main directory **⑥**, which lists all available menu items.
2. **Move Through Options:** Use the **UP button ③** and **DOWN button ⑤** to scroll and highlight the desired menu item in the directory.
3. **Select an Item:** Press the **OK button ②** to select the highlighted item and view the details or settings.
4. **Return:** To exit a screen and go back to the main directory, press the **BACK button ①**.



VEHICLE CARE AND MAINTENANCE

FUEL



Your RV runs on **regular unleaded gasoline (87 octane)**. For the best performance, fill up at well-known stations like Esso, Shell, Chevron, Husky, Petro-Canada, or Irving. Try to avoid smaller independent stations, as lower-quality fuel can sometimes clog pumps and lead to unexpected problems.

ENGINE OIL

For the best performance, check the engine oil every **1,500 km** when the engine is cold. If you need to top it up, please use only **SAE 5W30** and keep your receipts for reimbursement.

Friendly Reminder: Using the wrong fuel, oil, or fluids can cause damage, which the renter would be responsible for. If you're ever unsure, just give **OnRoad Support** a call—they're happy to help.

OIL CHANGE LIGHT ILLUMINATES

We change the oil in our vehicles every **12,000 km** following the manufacturer's recommendations. Sometimes the oil change light may come on a bit earlier due to the programmed schedule. You can find the last oil change recorded on the **windshield sticker**. If the sticker shows that an oil change is due, just give **OnRoad Support** a call—they'll direct you to an authorized repair shop. Please keep any receipts for oil purchases so we can reimburse you when you return the RV.

TIRES

TIRE CHECK

For a safe and comfortable drive, check the tire pressures regularly, making sure the tires are **cold** for the most accurate reading. The recommended tire pressure is listed on a sticker inside the driver-side door frame. Also, give the **wheel nuts a quick visual check** each time you leave a campground.

TIRE CHANGES

Tires should be changed only by **authorized personnel** from the **FORD Road-Side Assistance program** or **KalTire 24-Hour Service**. If you need a tire change, please contact **OnRoad Support**—their numbers are in the "Emergency" appendix as well as on the bottom of the page.

Only attempt to change a wheel yourself if you have no way to reach us, and please note that doing so is **at your own risk**. After changing a wheel, check the wheel nuts after **100 km** (or sooner) and retighten if needed to stay safe.

All tools needed for a tire change are stored in under the passenger side rear seat of the truck. They can be accessed by pulling the lever on the side of the backrest and folding the backrest forward.

Friendly Reminder: Improper tire changes or skipped checks can cause serious damage, which the renter would be responsible for.

VEHICLE SPECIFICATIONS

Motorhome class – Truck model	Truck Camper - FORD F-150 3.5 Litres V6 Gasoline
Roof air conditioner	No
Microwave	No
Convection oven	No
Oven	No
3-point-seat belts at dinette	No! The camper is not approved for passenger transport.
Bathroom vent	No
TV	No
DVD player	No
Rear dual tires	No
Propane-driven generator	No
Fuel-driven generator (gasoline)	No
Side slide-out	No
Rear slide-out	No
Sleeps	2
Seat belts	5
Fuel type	Gasoline
Bumpers	Steel
Locking lug nuts	Not available
Number of axles	2
Spare tire	Yes, stored in the rear under the chassis.
Tire size and pressure	Please see on a sticker inside the driver-side door frame.
Fire extinguisher	The fire extinguisher is located next to the entrance door.
Sewer hose	No

Dimensions & weight	Metric system	Imperial system
Height (incl. all superstructures)	305 cm	10'0"
Width	250 cm	8'2"
Length	623 cm	20'5"
Gross vehicle weight (GVW - i.e., weight incl. fuel, propane, wastewater and water tanks, maximum number of persons allowed, and luggage)	5,216 kg	11,500 lbs

Fill capacity (litres and gallons)	Metric system	Imperial system
Freshwater tank	18.9 liters	5 gal.
Grey water tank	N/A	N/A
Black water tank	3.78 liters	1 gal.
Fuel tank	136.27 liters	36 gal.
1 Propane bottle	4.5 KG	10 lbs


Interior specifications	Metric system	Imperial system
Overcab Queen bed	137 cm x 203 cm	59" x 77"
Rear queen bed	N/A	N/A
Dinette bed	89 cm x 178 cm	35" x 70"
Pull-out sofa bed	N/A	N/A
Electrically adjustable bunk bed	N/A	N/A
Interior room height	198.12 cm	78"

EXTERNAL VIEW



1. Fuel tank
2. Sink outlet
3. Storage compartment
4. Propane bottle
5. Awning

6. Solar panel
7. 2nd water tank
8. Porch light
8. Furnace with diesel tank
- 110/120V power connection for electrical hook up



ELECTRICAL SYSTEM

The camper uses a **YETI 3000 X Power Station** with a lithium camper battery.

Charging while Driving: Both the engine battery and the camper battery charge via the alternator while the vehicle is running, but they discharge independently.

External Power: The battery also charges when connected to an external **230W power supply**.

Solar Power: Additional charging is provided by the roof-mounted **solar panel**.

- ① **Input for charging**
- ② **Input for charging**
- ③ **Input for charging**

The power station uses these connections to draw charge from three sources: SOLAR, EXTERNAL POWER (Shore Power), and the ALTERNATOR (Engine).

Safety Warning: For your protection and to prevent damage, please do not touch the connections.

- ④ **12V Outputs**

12V DC Output: Press the corresponding button to enable power for 12V appliances. Crucially, this switch must remain ON to operate the lights, thermostat, and refrigerator.

- ⑤ **USB A + C Outputs**

USB Ports: Press the corresponding button to activate the USB charging ports.

- ⑥ **110/120V Outputs**

110/120V AC Output: Press the corresponding button to enable power for standard 110/120V appliances.

- ⑦ **Interactive Buttons and LCD Screen**

Ⓐ **UNIT**

Cycles through display settings. Must be set to display WATTS.

Ⓑ **LIGHT**

Press to "wake up" the power system display

Ⓒ **INFO**

Press to display the hours remaining until the system is fully charged or fully emptied.

Ⓓ **INPUT**

Shows the power (in watts) flowing *into* the Yeti while charging.

Ⓔ **OUTPUT**


Shows the power (in watts) being *used* by currently connected devices.

Ⓕ **BATTERY LEVEL**

Shows the current percentage of remaining battery charge.

Ⓖ **TIME**

Shows the estimated hours until the system is fully charged or fully emptied based on current usage.



CONNECTING TO EXTERNAL POWER (110V)

A power cable is supplied with your camper to connect to the campsite's 110V external power supply.

Standard Connection: The regular plug is designed for a **30 AMP** connection, which is standard at most campgrounds.

Adapter: An adapter is provided for use when only a **15 AMP** connection is available.

Connection Location: The connection port is located on the **passenger side** of the camper unit.

WATER SYSTEM

The The SCOUT OLYMPIC features a **gravity-fed water system** with exterior drainage. A spare water tank is also attached to the exterior of the camper.



FILLING THE TANK

You have two options for filling the water tank:



1. **Remove and Fill:** Unscrew the tank from the wall (using screws ②), open the water tank cap ①, and fill it anywhere.
2. **External Fill:** Leave the tank mounted and use a long water hose to fill it from the outside.



Dispensing Water

Use the water tank cap ① as a **mechanical pump** to draw water and dispense it through the spray head ③.

TOILET

The unit is equipped with a **portable toilet** ①.



Location

The toilet is stored in a designated area:

- **Underneath** the fridge.
- Right **beside** the power system.

Emptying

To empty the portable toilet, simply **carry it straight to the dump station**.

OPERATING THE DIESEL HEATER



Your camper is equipped with an efficient diesel heater to keep you warm.

The required diesel fuel is drawn from the dedicated **diesel tank** ① which is externally mounted ② on the camper.



To turn on the heater: Locate the **furnace controller** ①, press the **heating mode button** ③. This will take you to the **thermostat screen** ①. Simply use your finger on the screen to adjust the desired temperature ④.

Cooking ON THE PROPANE STOVE TOP

Your camper is equipped with a propane-powered **two-burner stove top** for cooking. The necessary **propane bottle** is securely stored in the designated outside compartment, located on the passenger side of the vehicle.



FRIDGE

Your refrigerator offers flexible power options, operating on either **AC (110/120V)** or **DC (12V)**. We **strongly recommend using the 12V DC power source** for reliable operation.

The unit features **two compartments** that can function as both a refrigerator and a freezer, depending on the temperature you select.

The control panel manages these functions and displays the current settings.

- | | |
|--|--|
| ① ON/OFF Switch | ⑤ Shows temperature or OFF status for SMALL compartment. |
| ② Sets temperature settings Celsius or Fahrenheit, battery monitor, brightness of display. | ⑥ Status SMALL compartment:
LED BLUE = Cooling
LED OFF = Not cooling |
| ③ Status LARGE compartment:
LED BLUE = Cooling
LED OFF = Not cooling | ⑦ Press once to decrease temperature. |
| ④ Shows temperature or OFF status for LARGE compartment. | ⑧ Press once to increase temperature. |



AWNING

Your vehicle is equipped with a **manually operated awning**.

Extending the Awning

1. Open the safety lever ①.
2. Open the pressure buttons ②.
3. Pull the awning all the way out. (Picture ② shows the extended position.)



Retracting the Awning

1. Carefully push the awning back in.
2. Secure it again using the safety lever ① and pressure buttons ②. (Picture ① shows the retracted position.)

Important Safety Rules

- **Weather:** Never use the awning in **stormy weather** or **strong winds!**
- **Time/Attention:** The awning **must be retracted overnight** or when the RV is **unattended**.
- **Space:** Before extending, ensure **sufficient space is available**.
- **Movement:** **Do not reposition the vehicle with the awning extended**, and always ensure the awning is retracted before **driving**.

Friendly reminder: The renter is liable for all damage resulting from **improper operation** of the awning.

BEDS

The Scout Olympic features a permanent Alcove bed ①. An extra sleeping area can be easily constructed by folding down the table ② and using the designated cushions ③ to form the mattress.



SAFETY EQUIPMENT

FIRE EXTINGUISHER

A fire extinguisher is an essential part of the safety equipment provided in every motorhome.

- **Location:** Please refer to the "**Vehicle Specifications**" section of this manual for the exact location of the fire extinguisher within your RV model.
- **Action:** Familiarize yourself with its location and operating instructions immediately upon taking possession of the motorhome.

SMOKE DETECTOR/CARBON MONOXIDE ALARM



Your RV is equipped with a **combined carbon monoxide (CO) alarm and smoke detector** for your safety.

Carbon monoxide is a **colorless and odorless gas** that can be deadly. It can be released by malfunctions in the burner systems of the stove, oven, or furnace.

Continuous Alarm (Loud Beeping): Indicates excess CO detected. **Immediately** turn off all appliances, open all windows/skylights, and evacuate the RV. Seek medical attention if symptoms of poisoning are present.

Prevention: Always ventilate well while cooking. Open a skylight and/or window when using the stove or oven

Battery Maintenance

If the alarm device beeps in **short intervals** without triggering a full continuous alarm, the batteries need to be replaced.

Action: Replace the batteries immediately to ensure the device's working condition and your safety.

Reimbursement Note: Please keep all receipts for battery purchases for reimbursement.

PROPANE DETECTOR/ALARM



Your RV is equipped with a propane detector, typically located near the floor.

- **Function:** The alarm sounds (continuous beeping) if an increased propane emission is detected (e.g., from the stove or oven).
- **Maintenance:** Do not place any objects on or near the detector to prevent false alarms.

Low Battery Warning

The propane detector is powered by the coach battery. If the detector emits a **beep every 30 seconds**, it indicates that the coach battery level is too low.

Recharge the coach battery immediately to ensure the detector remains functional and your safety is maintained.

If the propane alarm sounds:

1. **Turn off the propane supply** on the main tank.
2. **Open all windows and doors** and **wait outside** the motorhome until the alarm stops.
3. **Once silenced**, verify that the stove and oven control knobs are fully off and safely check for any propane leaks. If the propane alarm does not stop, please call our OnRoad Department.

RETURNING THE VEHICLE

To ensure a seamless return process and help us keep our vehicles in top shape for the next adventurer, please follow this checklist.

RETURN TIME

The vehicle must be returned to the rental station **no later than the exact time specified in your rental agreement**, and **ready for immediate inspection**. Please allow yourself sufficient time to pack up all belongings **before** your scheduled return time.

LATE RETURNS

If you anticipate being late, you **must** seek prior approval from our rental station.

If the vehicle is returned late **without prior approval**, an **hourly late fee** will be charged, as detailed in your "Terms & Conditions."

TANK PREPARATION (REQUIRED)

To avoid service fees, please ensure the following tasks are handled before return:

Fuel Tank: Must be **FULL**.

Waste Tanks: The black water tank (toilet) and the grey water tank (sink/shower) must be **EMPTIED**. The propane and water tanks can be left as is.

VEHICLE CONDITION (REQUIRED)

Interior Condition: Please return the vehicle with the interior **reasonably clean**. This means dishes done and put away, tidying up, sweeping the floor, cleaning liquid spills and removing all personal trash.

No Smoking Policy: Smoking (including vaping) is strictly prohibited inside the vehicle. Violators will be fined according to the "Terms & Conditions."

TRAFFIC VIOLATIONS

Renters are fully liable for all traffic violations (tickets, fines, etc.) committed during the rental period.

Please pay any ticket received before return. Many tickets have an online payment option.

For any delays in payment, a **processing fee** will be charged in addition to the actual ticket amount.

Thank you! We pride ourselves on the condition of our fleet. Your cooperation is greatly appreciated!

If you have any questions or concerns during your trip, please don't hesitate to contact us.

Your rental team wishes you a pleasant and unforgettable time!

Your FRASERWAY & FOUR SEASONS Team



Disclaimers:

Features, components and appliances depicted in this manual may differ from your rental motorhome depending on the model year. All features, components, appliances, materials, instructions, and guidance depicted and/or described in the manual and documentation are as accurate as possible at the time of creation and initially published but may not be accurate as a result of your rental motorhome having been assembled on a date after the manual or document was produced and initially published. Fraserway RV LP reserves the right to make changes, substitutions and improvements to its products without prior notification. This manual is for demonstrative purposes only. If you are still unsure on how to properly operate any appliance or feature addressed by the manual or documentation, please consult with your local Fraserway RV rental branch directly. This manual is © 2025 Fraserway RV LP, and all related marks, logos, and model names are owned by Adventurer Manufacturing LP and Fraserway RV LP, Inc. or its licensor(s). No portion of this manual may be copied, altered, published, displayed, broadcast, or otherwise used without the express permission of Fraserway RV LP, Inc. All rights reserved.

Version Feb 2026